

SBOX

</

1

A (x1) B (x1)

C (x1) D (x1)

M-A (x4) M6x30 M-B (x4) M8x30

M-C (x4) D8 M-D (x4) Ø15xØ8x15

W-A (x4) ST6.3x55 W-B (x4) Ø10x45 W-C (x4) D6

2

55mm (2.2") Ø 4.5mm (ø 3/16")

A B

W-C W-A

3

60mm (2.4") Ø 10mm (ø 3/8")

A B

W-B W-C W-A

4

NOTE: Adjust to the desired angle and then tighten the knobs as shown.